

USER GROUP: 2-5 Years, 5-12 Years

RECOMMENDED CREW: 1-2 People

TOOLS REQUIRED:

- TT-45 Torx, 9/16" Hex
- Level, Square, Hammer / Mallet, Plastic / Metal Saw
- Auger / Post Hole Digger / Shovel
- Drill Bits: None
- High Speed 3/8" Electric Drill with Clutch
- Framing, Bracing, or Concrete Forms (Not Included)
- High Speed 3/8" Electric Drill with Clutch

NOTE: Use of any other driver may result in damage to product, tool, and/or hardware!

NOTE: Apply Thread Locking Solution to ALL Non-Patched Hardware with Threads!

INSTALLATION TIME: 1 Hour

WEIGHT: 100 lbs.

CONCRETE REQUIRED: (20) 80lb. bags - 12.0 ft³

NOTE: Concrete must have a minimum rating of 2,500 psi and must be mixed per manufacturer's recommendations.


ITEM	Part No.	QTY	DESCRIPTION
1	30003011XX	1	Post w/Dome Cap 136" Length - 3.5"
2	FIT07728XX	1	Fitness Stretching Post 76"
3	FIT07668XX	1	Fitness Stretching Post 66"
4	FIT07608XX	1	Fitness Stretching Post 64"
5	RSP07546XX	3	Routed Sheet Plastic - Stretch Pole Pad
6	HWB0222	12	Bolt 3/8"-16 x 1-1/2" TORX Security with Patch SS
7	HWWR0092	24	Washer 3/8" ID x 1-1/4" OD x 0.12 thick Flat SS
8	HWN0095	12	Nut 3/8"-16 Hex Nut 300 S/S

PRE-INSTALLATION CHECK:

Customer is responsible for verifying materials received by comparing received items with packing list. If any parts are missing or damaged, including documentation, contact your local sales representative immediately.


Supplier is not responsible for items discovered missing after 72 hours from time of delivery.

Before beginning installation, all installers must read and understand the Installation Introduction manual as supplied. If you did not receive a copy, or if you have any questions regarding any information in the Installation Instructions or this Installation Guideline, contact your local sales representative.



STEP 1


Mount pad panels to support posts. For each post, align holes in panel with slots in plate on support post. Secure with four (4) 3/8" x 1-1/2" security Torx, eight (8) 3/8" x 1-1/4" flat washers, and four (4) 3/8" Nylon lock nuts. Repeat for all support posts with plates.



STEP 2

Set support posts. Refer to site plan drawing and site elevation drawing for placement of all support posts. Installer is responsible for proper location of all support posts. Support post spacing is shown below. Footing holes for support posts must be 18" diameter and 24" deep plus 12" surfacing. If surfacing is less than 12", deepen footing holes as needed. Place posts into footing holes and plumb. See Detail 2-1 for post pad elevations. Fill each footing hole with concrete to within 3" from ground surface. Allow concrete to cure based upon manufacturer's instructions. Backfill each footing hole with dirt, flush with grade. See Detail 2-2. Check all connections and ensure structure is stable. All concrete must be fully cured before use of structure. Installation is complete.

Detail 2-1



Detail 2-2

