

USER GROUP: 12 Years to Adult

RECOMMENDED CREW: 1-2 People

TOOLS REQUIRED:

- Level, Square, Hammer / Mallet, Plastic / Metal Saw
- Auger / Post Hole Digger / Shovel
- Drill Bits: None
- Framing, Bracing, or Concrete Forms (Not Included)


INSTALLATION TIME: 1 Hour

WEIGHT: 174 lbs.

CONCRETE REQUIRED: (8) 80lb. bags - 4.8 ft<sup>3</sup>

NOTE: Concrete must have a minimum rating of 2,500 psi and must be mixed per manufacturer's recommendations.

ITEM	Part No.	QTY	DESCRIPTION
1	FIT21006XX	2	Wldmt - Fitness Balance Beam 6 ft.



### PRE-INSTALLATION CHECK:

**Customer is responsible** for verifying materials received by comparing received items with packing list. If any parts are missing or damaged, including documentation, contact your local sales representative immediately.

**Supplier is not responsible** for items discovered missing after 72 hours from time of delivery.

**Before beginning installation, all installers must read and understand the Installation Introduction manual as supplied.** If you did not receive a copy, or if you have any questions regarding any information in the Installation Instructions or this Installation Guideline, contact your local sales representative.

# INSTALLATION GUIDELINE

## STEP 1

Prepare footing holes. Refer to site plan drawing and site elevation drawing for placement of all support posts. Installer is responsible for proper location of all support posts. Footing hole spacing is shown at right. Footing holes must be 12" diameter plus depth plus 12" surfacing. Footing hole depths are shown at right. Place one block (not included) beneath each support post. See Detail 1-1. If surfacing is less than 12", deepen footing holes as needed. Place beams into footing holes. Ensure blocks are beneath all support posts. Ensure each beam is level. Beam elevations are shown below. Complete setting of footing holes. Fill footing holes with concrete to within 3" from ground surface. Allow concrete to cure based upon manufacturer's instructions. Backfill footing holes with dirt, flush with grade. See Detail 2-1 for footing hole details. Check all connections and ensure structure is stable. All concrete must be fully cured before use of structure. Installation is complete. Place one (1) Age Appropriate Sticker on structure in a clearly visible location.

## Detail 1-1

